

Quick start quide

CLP99183/CLP99283/CLP99353/CLP99383/CLP99453/ CLP99483/CLP99553/CLP99583

This quick start guide provides you with basic instructions only. For more complete instructions, please refer to the user's manual in the package, or download it at www.telephones.att.com/manuals.

Parts checklist

Your package contains:

- Handset
- (1 for CLP99183)
- (2 for CLP99283) (3 for CLP99353/CLP99383)
- (4 for CLP99453/CLP99483)
- (5 for CLP99553/CLP99583)
- Charger with power adapter (1 for CLP99283)
- (2 for CLP99353/CLP99383)
- (3 for CLP99453/CLP99483) (4 for CLP99553/CLP99583)
- Telephone base
- Telephone line cord
- Telephone base power adapter

- Battery compartment cover (1 for CLP99183)
- (2 for CLP99283)
- (3 for CLP99353/CLP99383)
- (4 for CLP99453/CLP99483) (5 for CLP99553/CLP99583)
- Battery
- (1 for CLP99183)
- (2 for CLP99283)
- (3 for CLP99353/CLP99383) (4 for CLP99453/CLP99483)
- (5 for CLP99553/CLP99583)
- User's manual
- Quick start quide

Basic steps to set up & operate your phone

Basic installation

- 1 Install telephone base & charger
- 2 Install handset battery
- 3 Install telephone base on the wall (optional)


Common settings

- 4 Set date and time
- 5 Set ringer volume
- 6 Add a Bluetooth cell phone / headset
- Download a cell phone directory
- 8 Record own announcement
- 9 Set number of rings


Common operations

- 10 Directory
- 11 Caller ID

Install telephone base & charger



Install handset battery








- Charge for at least 30 minutes before initial settings.
- Charge for 11 hours before initial use.

Install telephone base on the wall (optional)

Follow the instructions only if you would like to mount the telephone on a wall.







INSTALLATION COMPLETED!

Keep reading for common settings and operations.



Set date and time

Set the date/time before using the answering system.

Using a cordless handset or the telephone base:

- 1. Press MENU -> Press V/▲ to Set date/time -> Press SELECT.
- 2. Enter the month (MM), day (DD) and year (YY) -> Press NEXT.
- 3. Enter the hour (HH) and minute (MM).
- 4. Press **▼**/**▲** to choose **AM** or **PM** -> Press **SAVE**.



Set ringer volume

You can set the ringer volume level to one of the six levels or turn the ringer off.

Using a cordless handset or the telephone base:

- 1. Press MENU -> Press V/▲ to Ringers -> Press SELECT.
- 2. Press **SELECT** to select **Ringer volume**.
- 3. Press ▼/▲ to choose the desired level -> Press SEI.



Add a Bluetooth cell phone / headset

To use a Bluetooth enabled cellular phone or headset with your telephone, you must first pair and connect your Bluetooth cellular phone or headset with the telephone base.

Bluetooth wireless technology operates within a short range (up to 30 feet). Keep the connected device within 15 feet of the telephone base for optimal performance.

To pair and connect a cell phone using the telephone base:

- 1. Press MENU -> Press V/▲ to Bluetooth -> Press SELECT.
- 2. Press **SELECT** to select **Add device**.
- 3. Press SELECT to select Add cellular.
- 4. Disconnect the cell phone from any Bluetooth device -> Press NEXT.
- 5. Place the cell phone next to the telephone base.
- 6. Press **NEXT** to turn on the telephone base discoverable mode.
- 7. Turn on the Bluetooth feature of your cell phone and search for or add new advices. Once your cell phone finds your AT&T phone (AT&T DECT 6.0), press the appropriate key on your cell phone to continue the pairing process.
- Enter the cell phone passcode (typically **0000**) if required -> **SET**.
- Enter the PIN (default PIN: 0000) of the telephone base into your cell phone if required.

To pair and connect a headset using the telephone base:

- 1. Press MENU -> Press ▼/▲ to Bluetooth -> Press SELECT.
- 2. Press **SELECT** to select **Add device**.
- 3. Press **▼**/**▲** to **Add headset** -> Press **SELECT**.
- 4. Disconnect your headset from any Bluetooth device -> Press NEXT.
- 5. Set your headset to discoverable mode -> Press NEXT
- 6. Press ▼/▲ to choose your headset if required -> Press **SELECT**.
- Enter the PIN (typically 0000) of your headset if required and press NEXT.



Download a cell phone directory

Before downloading a directory, make sure the cell phone is paired, active, and connected to your CLP99183/CLP99283/CLP99353/ CLP99383/CLP99453/CLP99483/CLP99553/CLP99583.

To download a cell phone directory using the telephone base:

- 1. Press MENU -> Press V/▲ to Bluetooth -> Press SELECT.
- 2. Press **▼**/**▲** to **Download dir** -> Press **SELECT**.
- 3. Press **▼**/**▲** to choose among **Phone memory**, **SIM card only** or **Phone** and SIM -> Press SELECT
- 4. Press **NEXT** to start downloading.
- Enter the cell phone passcode, if necessary, then press **SEI**.
- Press a key on your cell phone to confirm the directory download.
- 5. Press **OK** to exit.

If you are using Bluetooth-enabled cell phones with Android® OS 2.3 or above, you may also download the **Connect to Cell**™ application (consists of Caller ID manager and Alerts manager) using the Google Play® Store app to extend the flexibility of your CLP99183/CLP99283/CLP99353/CLP99383/CLP99453/ CLP99483/CLP99553/CLP99583. Scan the QR code on the right to download the application.



Record own announcement

You can use the preset announcement to answer calls, or replace it with your own recorded announcement.

Using a cordless handset or the telephone base:

- 1. Press MENU -> Press V/▲ to Answering sys -> Press SELECT
- 2. Press **SELECT** to select **Announcement**.
- 3. Press **SELECT** to select **Record annc**.
- 4. Facing the handset or telephone base, record your announcement and press **STOP** to end recording.



Set number of rings

You can set the answering system to answer an incoming call after 2, 3, 4, 5 or 6 rings, or toll saver. If you choose toll saver, the answering system answers a call after two rings when you have new messages, or after four rings when there are no new messages. This feature allows you to check for new messages and avoid paying long distance charges if you are calling from out of your local area.

Using a cordless handset or the telephone base:

- 1. Press MENU -> Press V/▲ to Answering sys -> Press SELECT
- 2. Press **▼**/**▲** to **Ans sys setup** -> Press **SELECT**.
- 3. Press **▼**/**△** to **# of rings** -> Press **SELECT**.
- 4. Press **▼**/**▲** to choose among **6**, **5**, **4**, **3**, **2** or **Toll saver** -> Press **SELECT**.

SETUP DONE!

Keep reading for some common operations.



The directory stores up to 200 entries.

To add an entry in the home directory:

Using a cordless handset or the telephone base:

- 1. Press MENU -> Press V/▲ to Directory -> SELECT.
- 2. Press **OPTION** to select **Home**.
- 3. Press **SELECT** to select **Add contact**.
- 4. Enter a telephone number -> Press NEXT.
- 5. Press **▼**/**▲** to select **Home**, **Cell**, **Work** or **Other** -> Press **NEXT**.
- 6. Enter a name -> Press **SAVE**.

To review and dial a directory entry:

Using a cordless handset or the telephone base:

- 1. Press DIR on the handset, or press DIRECTORY on the telephone base in idle mode -> Press **▼**/**▲** to select the desired directory -> Press **REVIEW**.
- 2. Press ∇/\triangle to browse through the directory, or press the dialing keys to start a name search.
- 3. Press **AHOME** or **●/SPEAKER** on the handset, or press **AHOME** on the telephone base to call using the home line.

-OR-

Press (P) CELL 1 or (P) CELL 2 to call using the cell line.



DIR

■1) (ABC2) (DEF3)

Caller ID

The caller ID log stores up to 50 entries.

To review and dial a caller ID entry:

Using a cordless handset or the telephone base:

- 1. Press CID on the handset, or press CALLER ID on the telephone base in idle mode -> Press **▼**/**▲** to scroll through the list.
- 2. Press **AHOME** or **●/SPEAKER** on the handset, or press **AHOME** on the telephone base to dial with the home line.

-OR-

Press (*) CELL 1 or (*) CELL 2 to dial with the cell line.

To erase the missed call indicator:

Using a cordless handset or the telephone base:

The screens display **XX missed calls** when you have incoming calls that have not been answered. When you have reviewed all the missed calls, the missed call indicator is erased.

If you want to erase the missed call indicator without reviewing the caller ID log, press and hold CANCEL in idle mode.





CALLER ID

Handset operation

(1)

CELL 2

6

MN0 6

REDIAL

PAUSE

DIR

VOLUME

(ABC 2)

JKL 5

45


8

MUTE

DELETE

GHI 4

SPEAKER



- Make or answer a cell call. Answer an incoming CELL 1/CELL 2 call during a CELL 1/CELL 2 call.

End a home or cell call.

Decrease the listening volume.

- Make or answer a home call.
- Answer a call waiting call during a home call.

Mute a call

• Delete a digit or character.

Press and hold to set QUIET mode or to deactive OUIET mode.

- Press repeatedly to review the redial list.
- Add a dialing pause while dialing or entering a number.
- Make a home call using the speakerphone.
- Answer a home or cell call using the speakerphone.

Answering system operation

Your telephone has a built-in answering system and supports voicemail feature offered by your telephone service provider (subscription is required, and fees may apply).

Answering system and voicemail

To use the built-in answering system:

Refer to this Quick start quide for basic instructions. For complete instructions, see the user's manual in the package, or download it at www.telephones.att.com/manuals.


YZ **9**

To use the voicemail:


PLAY/STOP

Press and hold ≥1 to dial the preset voicemail number, and then enter a security code. Contact your telephone service provider for detailed information.

The built-in answering system must be turned on to answer and record messages.



 Start message playback. Stop messge playback.



For a full set of installation and operation instructions, refer to the CLP99183/ CLP99283/CLP99353/CLP99383/CLP99453/CLP99483/CLP99553/ CLP99583 DECT 6.0 cordless telephone/answering system with BLUETOOTH® wireless technology user's manual in the package, or download it at www.telephones.att.com/manuals.

For customer service or product information, visit our website at www.telephones.att.com or call 1 (800) 222-3111. In Canada, dial 1 (866) 288-4268.

The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Advanced American Telephones and its parent, VTech Holdings Limited, is under license. VTech Holdings Limited is a member of Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective owners.

© 2013-2014 Advanced American Telephones. All Rights Reserved. AT&T and the AT&T logo are trademarks of AT&T Intellectual Property licensed to Advanced American Telephones, San Antonio, TX 78219. Android® and Google Play® are registered trademarks of Google Inc. Connect to cell™ is a trademark of Advanced American Telephones. Printed in China. Issue 3.0 AT&T 10/14.